


Introduction

Controller adopt the widely used 2.4G wireless technology with the features of low power consumption, long signal transmitting and strong anti-interference, etc. Controller has auto-transmitting and auto-synchronizing function. Widely used on the controlling of hotel lighting and home lighting.







RGBW LFD Controller Kits

Model No.: FUT038SA

LED Controller

Working Voltage: DC12V~24V Output: 6A/Channel

Total Output: Max 12A

RF: 2.4GHz

Control Distance: 30m

Working Temperature: -10~40°C Output Connection: Common anode

Rainbow Remote

Working Voltage: 3V(AAA*2PCS) Transmitting Power: 6dBm Standby Power: 20uA RF: 2.4GHz

Modulation Method: GFSK



16 Millions of colors to choose



Dim brightness / saturation



2.4G RF wireless transmission technology Support third party voice control (2.4GHz gateway is needed)

Remote control Control distance


Control distance 30m

Smartphone App control (2.4GHz gateway is needed)

Button Diagram



brightness, saturation, color temperature, RGB use together. (It turns to adjust brightness by default if remote is not operated for 3 seconds)



RGBW LED Controller Kit Model No.: FUT038SA

Install The Battery For Remote

Note: 2*AAA Battery need to buy seperately



1. Open battery cover behind remote



2. Install battery correctly and close battery cover.


Remote Instruction

- Adjust RGB Short press Rey twice in succession, and then touch to adjust RGB.
- Adjust color temperature Short press key once, then touch to adjust color temp.
- Adjust saturation Press key twice in succession, and then touch oto adjust color saturation of lighting.
- Adjust brightness Short press key once, then touch to adjust brightness.
- Dynamic mode switching Long press (on) key until indicator light flashes twice, then short press (ON) key to cycle switch. (Note: it will exit automatically if no operation after 3 seconds)

Linking Code / Unlinking Code Instructions

Attention: No need to match code since its already matched code in factory setting

Linking Code Instructions



Switch off controller. after 10 seconds then switch on again.



Short press "ON button 3 times within 3 seconds when light on.



slowly means linking is done successfully.



Linking failed if light is not blinking slowly, Please follow above steps again. (Note: controller that have linked can't link again)

Unlinking Code Instructions



Switch off controller after 10 seconds then switch on again.



Short press "ON button 5 times within 3 seconds when light on.



Lights blink 10 times quickly means unlinking is done successfully.



Unlinking failed if light is not blinking quickly, Please follow above steps again. (Note: controller haven't linked that don't need to unlink)

Signal transmitting

One controller can transmit the signals from the remote control to another controller within 30m, as long as there is a controller within 30m, the remote control distance can be limitless

Modes synchronization

Different controllers can work synchronously when they are started at different times, controlled by the same remote, under same dynamic mode and within 30m distance.



PWM high frequency / low frequency switching

Switch to high frequency (8KHz): on the condition of turning on the light

- 1. Short press the "OFF" button of the remote control once;
- 2. Short press the "ON" button 5 times within 3 seconds, the white light blink 2 times guickly, indicating successfully.

Switch to low frequency (500Hz): on the condition of turning off the light

- 1. Short press the "ON" button of the remote control once:
- 2. Short press the "OFF" button 5 times within 3 seconds, the white light blink 2 times slowly, indicating successfully.

Dynamic mode table

Number	Dynamic Mode	Brightness / Saturation
1	Mardi Gras	Adjustable
2	Automatic color change	
3	Sam	
4	Gemstone	
5	Twilight	
6	American	
7	Fat Tuesday	
8	Party	
9	Slow Color Splash	

Attention

- 1. Please check whether the voltage of the power supply is in accordance with the controller, and please check the connection of both the cathode and anode, otherwise the controller will be broken.
- 2. Please don't connect wires with power on. Please turn on again only when it is in right connection and no short circuit.
- 3. Please do not use the controller in the place with widely range metal area or strong electromagnetic wave nearby, otherwise, the remote distance will be seriously affected



